

	Z80 Alpha Plus			
	Original Memory Map (Z80 Alpha compatible)		Extended Memory Map (Alpha Plus mode)	
JP5	1-2		2-3	
JP6	1-2		2-3	
JP7	1-2		2-3	
JP8	1-2		2-3	
ROM	2k	0000-07FF	8k	0000-1FFF
Low RAM	2k	0800-0FFF	24k	2000-7FFF
High RAM	32k	8000-FFFF	32k	8000-FFFF